



Side Vents Perforated 2pc

1991-1994



AMERICAN CAR CRAFT INSTRUCTION

C4 91-94 Corvette Perforated Side Vents

Part# 022003 Patent Pending



PARTS INCLUDED:

- 2 or 4-Perforated Stainless Side Vents (depending on your year)
- 2-Packs Adhesive Promoter
- 1-Scotch Pad

1. Remove the vented body panel from the vehicle. This will require the removal of the three wheelwell screws and the two body bolts one on top and one under the car at the fender edge.
2. Once the panel has been removed scrub the inner side of the vent tabs thoroughly with alcohol to remove any and all road grime and dirt. You have been provided with a small scotch pad. Use this pad to rough the surface of the tabs and then scrub again. After this is done, swipe the tabs with the adhesive promoter provided.
3. Before you set the new grille place them in position to check the overall fit and also to get acquainted with just how they will sit in place. NOTE: The best position is one that will lean more towards the bottom of the vent opening. This will insure that there will be no gap visible when looking down on the vent opening.
4. Now that the surface of the tabs have been cleaned and prepped simply remove the red release liner from the attachment tape of the new grille then press them firmly in place to set the grille. Reinstall the body panel.
5. Repeat process for other side. Do not get wet for 24 hours.

Thank you and enjoy your purchase!

If any questions occur during installation, please contact

AMERICAN CAR CRAFT

18924 SAKERA ROAD-HUDSON FLORIDA 34667

Phone # 727-861-1500 Fax # 727-861-1520

www.americancarcraft.com