



## **AMERICAN CAR CRAFT INSTRUCTIONS**

### **Subaru Impreza Tag Frame “WRX” Style Part #182002**



**\*Carbon Fiber Tag Back Sold Separately\***

#### **PARTS INCLUDED:**

- 1-Chrome/Stainless/Carbon Fiber Tag Frame
- 2-M6-1.00x20mm Metric Hex Head Cap Screws
- 2-124NC 10mm Chrome Screw Covers

1. Remove screws from stock license frame.
2. Install new Tag Frame and install new hardware.
3. Snap Chrome Screw Covers over screw head.

**Thank you and enjoy your purchase!**

**If any questions occur during installation please contact  
AMERICAN CAR CRAFT  
18924 SAKERA ROAD-HUDSON FLORIDA 34667  
Phone # 727-861-1500 Fax # 727-861-1520  
[www.americancarcraft.com](http://www.americancarcraft.com)**