2011-2014



AMERICAN CAR CRAFT INSTRUCTIONS

Raptor 6pc Carbon Fiber Executive Cap Cover Part# 773009



PART INCLUDES:

5-3/4" caps 1-1/2" caps 6-Attachment Cookies 1-Pack Adhesive Promoter

- 1. The first step for installation will be to thoroughly scrub the tops of each of the factory caps, the oil/water/washer fluid/brake fluid/power steering and clutch fluid if so equipped. Scrub them with alcohol to remove any surface contaminants then swipe the tops with the adhesive promoter provided.
- 2. You have been provided with 2" furry Velcro attachment cookies for each cap. Peel the release liner from the back of each cookie and firmly set them to the top of each factory cap.
- **3.** The factory wind shield washer fluid cap will need to be trimmed slightly for the new cover to sit nice and centered. To do this, simply snip the finger tab as well as the attachment strap off the cap with scissors.
- **4.** The remaining covers in your kit are for all other factory caps. Simply set them in place.

Thank you and enjoy your purchase!

If any questions occur during installation, please contact AMERICAN CAR CRAFT 18924 SAKERA ROAD-HUDSON FLORIDA 34667 Phone # 727-861-1500 Fax # 727-861-1520

www.americancarcraft.com