



Chrome xB Grab Handle

INSTALATION INSTRUTIONS

Tools Required:

- A) Trusty Phillips Head Screwdriver
- B) 10mm Deep Socket
- C) Needle Nose Pliers

Install Time: Approximately 20 minutes

- 1) First remove your rear tailgate inner panel.
- 2) Remove and retain the 10mm nuts from the three studs.
- 3) On the right hand side there is a plastic retainer clip. Gently squeeze this with the needle nose pliers while pulling upward on the handle to gently remove.
- 4) Once the handle is free remove and retain the screws on the light fixtures then remove and retain the two screws on the touch pad.
- 5) The touch pad will still be held in place by two retaining clips. Gently squeeze these with the needle nose pliers one at a time to remove touch pad from handle.
- 6) Slide out the bronze colored middle stud and the plastic retainer on the right and place them into your new chrome handle.
- 7) Re-install your lights and touch pad into the new handle and run your wires back into the retaining channel.

You do not have to disconnect any of the wiring.

NOTE: DO NOT REMOVE THE PROTECTIVE PLASTIC FROM YOUR NEW PART UNTIL IT IS FULLY INSTALLED TO PROTECT THE CHROME FINISH. ALSO BE SURE TO PROTECT THE STUDS FROM DAMAGE BY EITHER TAPING THE THREADS OR PUTTING SOME SHRINK TUBE ON THEM BEFORE INSERTING BACK INTO THE BODY.

- 8) Re-install the nuts on the studs and snug in place.

DO NOT OVER TIGHTEN.

- 9) Replace your hatch panel.
 - 10) Remove protective plastic coating, and wax with a high quality wax.
- Stand back and watch it sparkle. This piece simply adds class to your ride!

**Da factory shoulda tawt about dis Bada Bling Bling!!!!
FORGETABOUDIT!**