



**AMERICAN CAR CRAFT INSTRUCTION**

**CORVETTE C-5 PERFORATED ALTERNATOR COVER**

**PART# 033051** patent pending



**ITEMS NEEDED:**

9/64 Drill Bit

**PARTS INCLUDED:**

2-Screws  
2-Plastic Washers  
2-Chrome Caps  
Stainless Alternator

1. Place your new cover into position.
2. Align the two holes in the cover with the main alternator bracket ridge. (This is a small area and must be matched up properly.)
3. Mark holes in cover to ridge in bracket using a fine point marker or scribe.
4. Using a 9/64 drill bit, drill marked holes only about 1/4" deep.

5. Place cover back over drilled areas and place screws (provided) through plastic washers then tighten. BE CAREFUL NOT TO OVER TIGHTEN. Push chrome caps (provided) onto screws until they snap into place.

**If any questions occur during installation, please contact American Car Craft at  
727-861-1500.**

**Thank you and enjoy your new purchase.**

**AMERICAN CAR CRAFT**  
18924 SAKERA ROAD-HUDSON FLORIDA 34667  
Phone # 727-861-1500 Fax # 727-861-1520  
[www.americancarcraft.com](http://www.americancarcraft.com)