



## AMERICAN CAR CRAFT INSTRUCTIONS

---

### C6 Z06 STYLE STAINLESS EXECUTIVE INLAYED DOORSILLS PART #041054



#### **PARTS INCLUDED:**

2-Stainless Doorsills

**Introduction:** PLEASE NOTE THAT THIS IS A PERMANENT INSTALLATION AND THE NEW DOORSILLS CANNOT BE REMOVED WITHOUT DAMAGING THE PART. PLEASE NOTE YOUR CAR WILL NOT BE DAMAGED IN ANY WAY.

**Liner Information:** Your new accessories will come to you with a protective surface liner. Leave this liner in place until the installation is complete to prevent finger prints and or possible scratches during installation.

1. Thoroughly clean the surface first with soap and water then with household isopropyl alcohol.
2. When you are satisfied with the fit, remove the red liner from the attachment tape, reposition your new sill and press firmly.

IT IS VERY IMPORTANT THAT YOU SLOWLY INSERT THE SILLS INTO PLACE. THE ATTACHMENT TAPE IS VERY RELIABLE AND IT MIGHT BE A GOOD IDEA TO MAKE A COUPLE OF TEST FITS BEFORE PULLING THE RED LINER!

**YOU HAVE ONLY ONE SHOT AT THIS SO GO SLOWLY!**

3. Once in place remove the protective liner. Repeat steps for the opposite doorsill.

If you have any questions during installation please call American Car Craft at 727 861-1500. Thank you and enjoy your new purchase.

**American Car Craft LLC**  
**18924 Sakera Rd Hudson, FL. 34667**  
**Ph 727.861.1500 Fax 727.861.1520**  
[www.americancarcraft.com](http://www.americancarcraft.com)