



AMERICAN CAR CRAFT INSTRUCTIONS

C6 CORVETTE GRAND SPORT LASER MESH 2PC SIDE VENT GRILLES

PART # 042081



Parts Included:

2x Stainless Grills

2xAdhesive Promoter Packs

1. Remove the retainers securing the Z06 style mud guard from the fender. You can do this by pulling the center nail out from the black plastic base of the retainer releasing it from the inner wheel well. Then pull the mud guard free from the fender this part of the mud guard is snapped in and need only be pulled to unsnap it. There is a small plastic hook at the top so after it is unsnapped simply pull it downward to release it. There is also on retainer attached to the underside of the fender area you will need to release this one as well.

2. Now that the mud guard has been removed you will notice two 9/32 body screws just under the fender. Remove these two screws and this will release the entire fender from the car allowing you to reach in and release the inner fender vent shield. This shield is just a simple plastic cover stuck to the inner fender wall and can simply be separated by hand, allowing you full access to the inner side of the fender vent openings. With the newly acquired access you can now thoroughly scrub clean the inner fender with alcohol to remove any road grime and dirt. Then swipe this area with the adhesive promoter provided. PLEASE NOTE: This chemical is not a cleaner but a very vital component that will insure that these peel and stick application will hold long term and must be used.

3. Each of the grand sport fender vent grills that will come to you are formed however it is essential that you further the shape and form to match the opening exactly in order to achieve the best end look and long term bond. Each of the grills has been designed to allow you to do this using your fingers or if you prefer a common plier to adjust each of the tapes so that they conform to the fenders inner contours. Once you have achieved a nice contour and shape with no gaps

simply peel the red release liner from the grills attachment tape and then carefully set them into position pressing firmly against the outside as well as the inside to achieve a nice complete bond. Once you have set the grill simply follow a reverse procedure to reassemble the wheel well and mudguard as well as the fender.

It is important to know the each of the grand sport grills will come to you looking like the top area is unfinished and may even appear defective. This is the design of the grill and will look just fine once it has been properly installed.

American Car Craft LLC
18924 Sakera Rd Hudson, FL. 34667
Ph 727.861.1500 Fax 727.861.1520
www.americancarcraft.com