



## AMERICAN CAR CRAFT INSTRUCTIONS

---

### C6 CORVETTE REAR TAILLIGHT TRIM

(fits all models)

*PART#042089*



**Parts Included:**

1x Adhesive Promoter Tube  
5x Chrome Strips

**Introduction:** This trim kit is an inexpensive and easy accessory to install. It is a simple yet dramatic look that you will enjoy for years to come.

1. Thoroughly clean the paint at the outer edge of the taillight with alcohol to remove any and all wax and dirt. Then swipe this perimeter once with the adhesive promoter tube supplied in your kit.
2. You will notice the end of each length of trim, the end cut is at a specific angle. Peel the red release liner completely from the back of each trim piece and then set the end directly to the paint nice and tight up against the plastic lenses making sure that you match the angle at the top of the lenses mounting tab. Set the trim so that it runs nice and smooth to the edge without creating any waves. Run the trim all the way around until you reach the other side of the lenses mounting tab. Although it should not be necessary to cut the trim if you have accumulated any excess trim simply snip any excess with a scissor or a wire cutter making sure you cut the end at the appropriate angle. Press firmly along the entire length to set the trim using a microfiber or any other soft cloth.

American Car Craft LLC  
18924 Sakera Rd Hudson, FL. 34667  
Ph 727.861.1500 Fax 727.861.1520  
[www.americancarcraft.com](http://www.americancarcraft.com)