



AMERICAN CAR CRAFT INSTRUCTIONS

C6 Executive Style Taillight Trim Polished 4pc **PART# 042117**



PARTS INCLUDED:

4-Stainless Taillight Trim Rings

4-C6 Crossed Flags Licensed Logo Emblems

2-Adhesive Promoter Tubes

INTRODUCTION: These all new designs are intended to fit directly onto the factory taillight transforming the plain taillight into an awesome retro style taillight. Fitted with the aftermarket graphic insert they will have a complete custom look.

PROTECTIVE LINER INFORMATION: Your new accessories will come to you with a protective surface liner. Leave this liner in place until the installation is complete to prevent finger prints and/or possible scratches during installation.

1. The first step will be the surface preparation. This procedure is a critical key step in the long term bond and success of the entire install. Wash the lens with soap and water to remove road grime and dirt. Then scrub the surface of the taillight lens first with household rubbing alcohol.

2. Apply masking tape to random areas of the taillight to see that the masking tape sticks well to the lens. Especially along the edges. If the tape sticks well then swipe the perimeter of the taillight with the adhesive promoter pen provided. TECH NOTE: Be careful not to allow the adhesive promoter to run all over the lens or allow your swipe to exceed the thickness of the outer taillight covers rim. The reason for this is that the adhesive promoter may tend to have an ashy look when dried. This will cause you to have to clean it which is extra work. It is also important that you apply the promoter along the outer edge only and not the center areas that contain the long extensions!
3. Now that the factory taillights are correctly prepped you can move onto attaching the covers. (TECH NOTE: Although it is not absolutely necessary you will find it a lot easier if you remove each taillight to install the new covers) These covers come to you preformed to match your taillights however it is imperative that you further shape the covers so that they match the taillight. This may require you to adjust the extensions in the cover so that they match your taillight without having to force them down. This will eliminate any possibility of the extensions popping up down the road. Take your time here to shape each cover. Once they match simply peel the red release liner from the back of the covers and firmly press them into place. Use a soft cloth to press along the entire surface to insure a good bond.
4. The last step will be to apply the emblem. Peel the protective liner. The center areas have been engraved with an outline. This outline will match the self stick emblem which will help you to place the emblem straight and center. Simply peel the emblem off its liner and then carefully set it into place pressing firmly to set the adhesive. Apply all four to finish the installation.

If you have any questions during installation please call American Car Craft at 727-861-1500.

Thank you and enjoy your new purchase.

AMERICAN CAR CRAFT
18924 SAKERA ROAD-HUDSON FLORIDA 34667
Phone # 727-861-1500 Fax # 727-861-1520
www.americancarcraft.com