



AMERICAN CAR CRAFT INSTRUCTIONS

2005-2013 C6 CORVETTE FENDER CAPS

PART#043095 patent pending



PLEASE TAKE THE TIME TO READ AND UNDERSTAND THE ENTIRE INSTRUCTIONS BEFORE BEGINNING THIS INSTALLATION.

PARTS INCLUDED:

2-Stainless Fender Liners

1- Promoter packet

Your new accessory comes to you with a clear protective liner. This liner will help to keep your new parts clean during installation. You will be instructed when to remove the liner during the detailed installation.

1. To install the long narrow fender liner cap cover. In order to install this apply some of the adhesive promoter provided over these two fender mount locations.
2. Place the cap cover in position so that the small notch aligns with the notch in the factory inner fender.(SEE PICTURE#13) It is important that these cap covers sit very tightly to the inner fender rubber gasket in order to achieve adequate clearances between the cap cover and hood when closed. (SEE PICTURES #14,#15) With this in mind simply fold

over a small section of the red release liner from the underside of the cap cover and set in place. Holding the cover tightly in position pull the red liner off the attachment tape as you firmly press the cap cover to set.



#13



#14



#15

Note: Care must be taken when cleaning your covers. It is a good idea to lightly dust your covers with a clean soft cloth first in order to prevent any particles from scratching them. Then wipe (using a new clean soft cloth) with a good quality streak free glass cleaner. SEE ENCLOSED CARE SHEET!

If any questions or problems occur during installation, please contact American Car Craft at 727-861-1500.

Thank You and Enjoy Your Purchase!

AMERICAN CAR CRAFT

18924 SAKERA RD HUDSON FL 34667

Phone: 727 861-1500

Fax: 727 861-1520

www.americancarcraft.com