



## **AMERICAN CAR CRAFT INSTRUCTIONS**

### **2008-2013 C6 Corvette GM Licensed 2pc Fuel Rail Covers Part #043115**



#### **PARTS INCLUDED:**

- 2-Stainless Fuel Rail Covers
- 1-Angle Chrome Cover w/Velcro
- 1-Pack of Adhesive Promoter

Your new covers come to you with a protective liner. **Do not remove liner until installation is complete.**

1. Your new fuel rail covers have been designed to snap over the existing factory covers. Simply remove the stock fuel rail covers and snap the new covers over top of them. Using a small rubber mallet tap the two small tabs over to lock in position and reinstall your covers.
2. Once you have successfully reinstalled your covers remove the protective liner.
3. You have been provided with a decorative chrome oil cap cover. Simply clean the top of the factory oil cap with household rubbing alcohol to remove dirt and road grime then swipe it once with the adhesive promoter pack provided. Remove the Velcro attachment cookie half from the underside of the cap cover and peel the release liner then place it on top of the factory oil cap and press firmly to set. Then simply position the new chrome cover in place.

**Thank you and enjoy your purchase!**

**If any questions occur during installation please contact  
AMERICAN CAR CRAFT  
18924 SAKERA ROAD-HUDSON FLORIDA 34667  
Phone # 727-861-1500 Fax # 727-861-1520  
[www.americancarcraft.com](http://www.americancarcraft.com)**