



## **AMERICAN CAR CRAFT INSTRUCTIONS**

### **2005-2008 C6 Corvette Carbon Fiber Crossed Flags Master Cylinder Cover w/Cap Part#043131**



#### **PARTS INCLUDED:**

- 1-Stainless Master Cylinder Cover w/Velcro Attachment Cookie
- 1-Adhesive Promoter Packet
- 1-Chrome Cap Cover w/Velcro Attachment Cookie

**Your new accessory comes to you with a clear protective liner. This liner will help to keep your new parts clean during installation. You will be instructed when to remove the liner during the detailed installation.**

This cool little cover is a nice way to just about instantly transform your stock master cylinder reservoir into a custom accessory which will look great in any C6 Corvette.

1. Thoroughly clean the top surface of the reservoir and the fluid cap with household rubbing alcohol to remove any road grime and dirt. Then swipe the areas with the adhesive promoter provided. Remove the factory fluid cap.
2. You will notice that your new cover has a Velcro attachment cookie mounted to the underside of it. Remove the cookie half and install it directly to the prepared surface of the reservoir.

3. Place the new cover over the reservoir pressing down gently to set in position. Replace the factory fluid cap and remove the protective liner.
4. You have been provided with a chrome cap cover that also has a Velcro attachment cookie. Simply remove the cookie half and mount it to the factory fluid cap pressing firmly to set. Then press the chrome cap in place.

**If any questions occur during installation please contact American Car Craft at  
727-861-1500**

**Thank you and enjoy your purchase!**

**AMERICAN CAR CRAFT  
18924 SAKERA ROAD-HUDSON FLORIDA 34667  
Phone # 727-861-1500 Fax # 727-861-1520  
[www.americancarcraft.com](http://www.americancarcraft.com)**