



AMERICAN CAR CRAFT INSTRUCTIONS

Challenger Fuel Rail Covers “392 HEMI” (Fits 6.4L Engine Only w/Factory Air Box) Part #153062



PARTS INCLUDED:

- 2-Stainless Valve Covers
- 2-Adhesive Promoter Packs

These new covers are made of the best quality 304 stainless polished to a beautiful mirror finish. They have been carefully designed to fit over the factory plastic covers and mount together via Velcro attachment tape.

Do not remove liner until instructed to do so.

1. Thoroughly clean the face of the factory covers with alcohol to remove any and all road grime and dirt. Then swipe the front 3 extruded areas above the coil packs with the adhesive promoter provided and lastly to the very front side of the plastic cover. This promoter is NOT a cleaner but an adhesive accelerator and will insure a nice permanent bond long term and MUST be used.
2. You have been provided with six Velcro attachment cookies. Peel the release liner from both sides of each cookie and place them to the 3 areas above the coil packs that you just promoted. The front side does NOT receive a Velcro cookie.
3. Swipe the underside of the new covers with the adhesive promoter and then carefully place them over the factory covers. Press them down firmly to set the Velcro cookies. Also at this time you might want to

firmly press the Velcro cookies on the underside of the covers to ensure a nice bond, and then simply reinstall.

4. At this time you may remove all the protective liner from the covers. NOTE: In some production models there may be a large wire harness routed in front of the factory fuel rail cover, should this be the case simply reroute the harness to the side to create adequate clearance for the new front plate. This may require you to detach the harness hold down from the valve cover bolts in order to allow you to force the harness cover to the side.

Note: Care must be taken when cleaning your covers. It is a good idea to lightly dust your covers with a clean soft cloth first in order to prevent any particles from scratching them. Then wipe (using a new clean soft cloth) with a good quality streak free glass cleaner.

Thank you and enjoy your purchase!

**If any questions occur during installation please contact
AMERICAN CAR CRAFT
18924 SAKERA ROAD-HUDSON FLORIDA 34667
Phone # 727-861-1500 Fax # 727-861-1520
www.americancarcraft.com**