



Doorsills Inner Polished 2pc

1997-2004



AMERICAN CAR CRAFT INSTRUCTION

C5 Corvette Polished Inner Doorsills

Part #031014



PARTS INCLUDED:

- 2-Polished Inner Doorsills
- 2-Pack of Adhesive Promoter

Please note this is a permanent installation and the new doorsills cannot be removed without damaging them.
Do not remove the liner until step 5.

1. Thoroughly clean the surface first with soap and water then with household isopropyl alcohol.
2. Then swipe the same area with the adhesive promoter (provided). This promoter will guarantee a good permanent bond.
3. It may be necessary to fit these sills by squeezing or opening them to insure a proper fit.
4. When you are satisfied with the fit, remove the red liner from the attachment tape and press firmly.

It is very important that you slowly insert the sills into place. The attachment tape is very reliable and it might be a good idea to make a couple of test fits before pulling the red liner!

YOU HAVE ONLY ONE SHOT AT THIS SO GO SLOWLY!

5. Once in place remove the protective liner. Repeat steps 1-5 for the opposite doorsill.

Thank you and enjoy your purchase!

If any questions occur during installation, please contact
AMERICAN CAR CRAFT
18924 SAKERA ROAD-HUDSON FLORIDA 34667
Phone # 727-861-1500 Fax # 727-861-1520
www.americancarcraft.com