



AMERICAN CAR CRAFT INSTRUCTION

CORVETTE 2-pc MONOGRAMMED VANITY PLATES

PART#031022



PARTS INCLUDED:

- 2-Vanity Plates
- 1-Adhesive Promoter Pack

1. Your new vanity plates are designed to fit just above your door sill area on the door jam. In order to install simply wipe this area clean first with soap and water and then with household isopropyl alcohol. Let dry then swipe once with the adhesive promoter pack provided. Then place your new plate into this area and make note of its position be sure that your plate is contoured to the shape of your door jam if not gently form by hand until your plate lays flat against the car. Once you are satisfied with the location remove the red liner from the attachment tape and reposition. Press firmly to set.

2. Repeat this process for the opposite side.

**If any questions occur during installation, please contact American Car Craft at
727-861-1500.**

Thank you and enjoy your new purchase.

Note: Care must be taken when cleaning your new plates. It is a good idea to lightly dust your plates with a clean soft cloth first in order to prevent any particles from scratching it. Then wipe (using a new clean soft cloth) with a good quality streak free glass cleaner.

AMERICAN CAR CRAFT

18924 SAKERA ROAD-HUDSON FLORIDA 34667

Phone # 727-861-1500 Fax # 727-861-1520

www.americancarcraft.com