



AMERICAN CAR CRAFT INSTRUCTION

CONVERTIBLE TRUNK LID PANEL

PART #031023



ITEMS NEEDED:

Household isopropyl alcohol
Clear household silicone

PARTS INCLUDED:

Adhesive Promoter

1. Remove the factory trunk lid liner if equipped. NOTE: Some C6 Models come equipped with a satellite antenna, if your car has this it will be necessary to cut the chrome trim over the notched area on the backside of your new panel in order to accommodate the antenna cable. Do this by simply using a straight razor blade to cut the trim out of the notch. Be careful not to put a cut mark in your panel.
2. You will notice two support beams in a U shape. These two beams must be scrubbed with household isopropyl alcohol, as well as the three recessed areas. Once cleaned apply the adhesive promoter (provided) to the two beams.

3. Next apply household silicone (in a HIGH pile) to the areas of your new panel marked with an X.
4. Remove the red liner from the 3M-attachment tape and carefully place the panel into place and press firmly to set at the beam areas.
5. Press the sides so that the silicone touches both the trunk lid and the new panel. It would be best to leave the trunk lid in the up position overnight until the silicone sets.

**If any questions occur during installation, please contact
American Car Craft at 727-861-1500.**

Note: Care must be taken when cleaning your panels. It is a good idea to lightly dust your panels with a clean soft cloth first in order to prevent any particles from scratching it. Then wipe (using a new clean soft cloth) with a good quality streak free glass cleaner.

**AMERICAN CAR CRAFT
18924 SAKERA ROAD-HUDSON FLORIDA 34667
Phone # 727-861-1500 Fax # 727-861-1520**

www.americancarcraft.com