



AMERICAN CAR CRAFT INSTRUCTIONS

C5 CORVETTE CHROME BUTTON KIT

PART#031024



Your kit comes to you with 60 chrome buttons and 60 sockets. This is more than you will need to complete this application. Save any extra parts in case you lose one. You have a choice of installation methods. You can either use method one or method two.

Method 1(PREFFERED METHOD)- The entire application can be done easily and securely by applying a small dab of clear household silicone from a small squeeze tube and gently place chrome cap into position. Be careful not to apply too much silicone as it will tend to ooze out of the sides. If this does happen leave it alone to dry. Once dry any excess can be pulled away cleanly.

Method 2(OPTIONAL)- You have been provided with 60 white snap sockets. Simply remove the screw you are going to cover with a T15 torx driver and slip it thru the white socket, replace the screw being careful not to over tighten. Then snap the chrome cover in place. Be sure that it snaps in place. However some of the screw heads may be too large for the socket, in this situation either replace the screw with one that will fit the socket or simply use method one and silicone cap in place.

If any questions occur during installation please contact American Car Craft at 727 861-1500. Thank you and enjoy your purchase!

AMERICAN CAR CRAFT
18924 SAKERA RD HUDSON FL 34667
Phone: 727 861-1500 Fax: 727 861-1520

www.americancarcraft.com