



AMERICAN CAR CRAFT INSTRUCTIONS

Corvette 4pc Stainless Steel Brake Pad Covers

Part# 032012



PARTS INCLUDED:

2-Front Brake Pad Plates
2-Rear Brake Pad Plates

1. Jack up your car and place it on a pair of jack stands for safety then remove the wheel.
2. Remove both caliper retaining bolts and remove caliper.
3. Compress the caliper piston slightly to create the clearance for the new brake pad cover.
4. Remove the outer brake pad and apply a small smear of household silicone to the back of your new stainless pad plate and place it over the brake pad.
5. Reposition the pad and reposition brake caliper and tighten **SECURELY!**
6. Follow steps 1- 5 for your 3 remaining wheels.

PLEASE NOTE: These custom pad covers in **NO** way alter your braking system. American Car Craft and its distributors will not be responsible for any improper installations; such as loose bolts or improper placement that may cause any danger or damage in any way, shape or form. Please follow instructions carefully and be sure to put your brakes back together safely and securely!

Thank you and enjoy your purchase!

If any questions occur during installation, please contact
AMERICAN CAR CRAFT
18924 SAKERA ROAD-HUDSON FLORIDA 34667
Phone # 727-861-1500 Fax # 727-861-1520
www.americancarcraft.com