



AMERICAN CAR CRAFT INSTRUCTIONS

C5 Corvette GM Licensed Rear Tag Frame

Part #032050



PARTS INCLUDED:

- 1-Chrome/Stainless/Carbon Fiber Rear Tag Frame
- 2-#12x1-1/2" Phillips Pan Head Screws
- 2-White Sockets
- 2-Large Chrome Screw Covers

1. Remove screws from stock license frame.
2. Install new Tag Frame and install new hardware.
3. Snap Chrome Screw Covers over screw head.

**If any questions occur during installation please contact American Car Craft at
727-861-1500**

Thank you and enjoy your purchase!

**AMERICAN CAR CRAFT
18924 SAKERA ROAD-HUDSON FLORIDA 34667
Phone # 727-861-1500 Fax # 727-861-1520
www.americancarcraft.com**