1997-2004



AMERICAN CAR CRAFT INSTRUCTIONS

C5 Corvette Washer Fluid Tank Cover Polished w/Cap Covers Manual Transmission Part #033018



PARTS INCLUDED:

- 2-Stainless Covers
- 4-2" Velcro Cookies
- 2-Packs of Adhesive Promoter
- 2-Chrome Caps

Your new covers come to you with a protective liner. Do not remove this liner until installation is complete.

- 1. Thoroughly clean the fender area with household isopropyl alcohol to remove any and all road grime and dirt. Once clean swipe the area to be mounted once with the adhesive promoter provided.
- 2. Before installing your new covers you will need to create some clearances.
- **3.** Once you have created the needed clearance insert the panels to check the fit. Once you are satisfied with the placement and fit peel the release liner from the attachment tape on the back of each cover then press firmly to set in place.
- **4.** Remove protective liner.

Thank you and enjoy your purchase!
If any questions occur during installation please contact
AMERICAN CAR CRAFT
18924 SAKERA ROAD-HUDSON FLORIDA 34667
Phone # 727-861-1500 Fax # 727-861-1520

www.americancarcraft.com