



AMERICAN CAR CRAFT INSTRUCTION

CORVETTE C5 ALTERNATOR COVER

PART# 033041 patent pending



Items Needed:
9/64 Drill Bit

Parts Included:
2-Screws
2-Plastic Washers
2-Chrome Caps
Stainless Alternator

1. Place your new cover into position.
2. Align the two holes in the cover with the main alternator bracket ridge. (This is a small area and must be matched up properly.)
3. Mark holes in cover to ridge in bracket using a fine point marker or scribe.
4. Using a 9/64 drill bit, drill marked holes only about 1/4" deep.

5. Place cover back over drilled areas and place screws (provided) through plastic washers then tighten. BE CAREFUL NOT TO OVER TIGHTEN. Push chrome caps (provided) onto screws until they snap into place.

**If any questions occur during installation, please contact American Car Craft at
727 -861-1500.**

Thank you and enjoy your new purchase.

AMERICAN CAR CRAFT
18924 SAKERA ROAD-HUDSON FLORIDA 34667
Phone # 727-861-1500 Fax # 727-861-1520
www.americancarcraft.com