



AMERICAN CAR CRAFT INSTRUCTION

C5 FRONT PERFORATED LIT NOSE CAP

PART# 033055_{patent pending}



PARTS INCLUDED:

1-STAINLESS STEEL NOSE CAP
1-COUNTER SINK BIT
6-STAINLESS FLAT HEAD SCREWS
1-ADHESIVE PROMOTER PACK

1. Remove the six bolts holding the top of the urethane bumper **MAKE NOTE** of where any U-shaped body spacers are placed at this area and remove (set aside) **NOTE: Not all cars will have these.** Then remove the body clip nuts just under the urethane bumper.
2. Mark a dot 1/4 inch in front of the newly exposed holes (towards the front of the car) in the urethane bumper and drill a 1/8 inch hole thru the bumper at these dots and down thru the actual bumper tab just underneath.
3. Using the counter sink (provided) bore the 1/8 inch holes set in the urethane bumper **ONLY**. Be careful to bore all six holes just large enough to allow the six stainless flat head screws (provided) to fit flush.

4. At this time replace the U-shaped body spacers (if equipped) back to there original locations allowing the U-shape to go around the newly drilled holes.
5. Using #2 Phillips head screwdriver or screw gun fasten the urethane bumper back into position using the six stainless flat head screws (provided). BE CAREFUL NOT TO OVER TIGHTEN.
6. Now that you have created a nice smooth and flush surface for your new front nose cap to bond to, you need to prep the surface by removing any dirt. First wash with soap and water then scrub with household isopropyl alcohol. Next apply the adhesive promoter (provided) to the entire area.
7. Now you are ready to install your new nose cap. First place nose cap in place to check fit, once you are satisfied remove the red liner from the attachment tape and reposition. Press firmly to set.

Installation procedure for the Lighted Version: This part of the installation is relatively easy but will take a little more time

1. The first step will be to create a 12v source for your new cover. This will require you to choose a good location for a switch. We recommend that this be placed directly through the black plastic battery shroud. This will make it very easy to use the switch and tap the batteries positive and negative posts to supply your new cover with a reliable power source. **(The switch, fuse and wire for this are not included.)**

Note: Care must be taken when cleaning your cover. It is a good idea to lightly dust your cover with a clean soft cloth first in order to prevent any particles from scratching it. Then wipe (using a new clean soft cloth) with a good quality streak free glass cleaner.

**If any questions occur during installation, please contact American Car Craft at
727-861-1500.**

Thank you and enjoy your new purchase.

**AMERICAN CAR CRAFT
18924 SAKERA ROAD-HUDSON FLORIDA 34667
Phone # 727-861-1500 Fax # 727-861-1520
www.americancarcraft.com**