



AMERICAN CAR CRAFT INSTRUCTIONS

C5 Corvette 6pc Cap Cover Set Standard

Part #033082 Patent Pending



PARTS INCLUDES:

4-3/4" Caps (Brake Fluid Reservoir, Clutch Fluid Reservoir, Coolant Reservoir, & Washer Fluid Reservoir)
1-1/2" Cap (Power Steering Fluid Reservoir)
1-Pack Adhesive Promoter

1. The first step for installation will be to thoroughly scrub the tops of each of the factory caps, the oil/water/washer fluid/brake fluid/power steering and clutch fluid if so equipped. Scrub them with alcohol to remove any surface contaminants then swipe the tops with the adhesive promoter provided.
2. You have been provided with 2" furry Velcro attachment cookies for each cap. Peel the release liner from the back of each cookie and firmly set them to the top of each factory cap.
3. The factory windshield washer fluid cap will need to be trimmed slightly in order for the new cover to sit nice and centered. To do this, simply snip the finger tab as well as the attachment strap off the cap with a scissor.
4. Simply set them in place and you're done!

Thank you and enjoy your purchase!
If any questions occur during installation please contact
AMERICAN CAR CRAFT
18924 SAKERA ROAD-HUDSON FLORIDA 34667
Phone # 727-861-1500 Fax # 727-861-1520
www.americancarcraft.com