



AMERICAN CAR CRAFT INSTRUCTION
C5 Corvette Carbon Fiber/Brushed Battery & Fuse Box Cover
Part# 033089



PARTS INCLUDED:

- 1-Battery Cover
- 1-Fuse Box Cover
- 1-2" Brushed Stainless Screw Cover w/Velcro
- 1-Adhesive Promoter Pack
- 1-Velcro Attachment Dot

1. Remove fuse relay cover and the rubber seal surrounding the battery box.
2. Place stainless steel cover over the hood stop and insert the panel into the ridge surrounding the battery.
3. Replace the rubber seal around the battery box.
4. Turn over the fuse relay cover and remove attachment screw by spreading the slits holding screw in place.
5. Slide off the positive battery post cover. This cover will not be reused.
NOTE: This is attached to the Fuse Relay Cover.
6. Place a few dabs of household silicone to both ends of the cover and place the cover over the Fuse Relay Cover.

7. Snap attachment screw back in and screw cover in place. You have been supplied with a round screw cover simply swipe the top of the attachment screw with the adhesive promoter provided and place the Velcro attachment dot directly to the screw head. Then you can attach the 2" stainless screw cover in place. **NOTE:** This cover will need to be removed to gain access to the attachment screw.

Thank you and enjoy your purchase!
If any questions occur during installation please contact
AMERICAN CAR CRAFT
18924 SAKERA ROAD-HUDSON FLORIDA 34667
Phone # 727-861-1500 Fax # 727-861-1520
www.americancarcraft.com