



AMERICAN CAR CRAFT INSTRUCTION

C6 Corvette Doorsills

Part #041017 patent pending



PARTS INCLUDED:

2-Stainless Doorsills

2-Adhesive Promoter

PLEASE NOTE THAT THIS IS A PERMANENT INSTALLATION AND THE NEW DOORSILLS CANNOT BE REMOVED WITHOUT DAMAGING THE PART. PLEASE NOTE YOUR CAR WILL NOT BE DAMAGED IN ANY WAY.

Your new doorsills come to you with a protective liner that you will remove after installation. This will help produce a nice clean install.

1. Thoroughly clean the surface area first with soap and water then with household isopropyl alcohol.
2. Then swipe the same area with the adhesive promoter (provided). This promoter will guarantee a good permanent bond.
3. When you are satisfied with the fit, remove the red liner from the attachment tape and firmly press.

IT IS VERY IMPORTANT THAT YOU SLOWLY INSERT THE SILLS INTO PLACE, KEEPING THE LARGE FLAP AWAY FROM THE CAR. THE ATTACHMENT TAPE IS

VERY RELIABLE AND IT MIGHT BE A GOOD IDEA TO MAKE A COUPLE OF TEST FITS BEFORE PULLING THE RED LINER!

YOU HAVE ONLY ONE SHOT AT THIS SO GO SLOWLY!

4. Once in place pull the protective liner off the sills.

If you have any questions during installation please call American Car Craft at 727-861-1500. Thank you and enjoy your new purchase.

Note: Care must be taken when cleaning your sills. It is a good idea to lightly dust your sills with a clean soft cloth first in order to prevent any particles from scratching them. Then wipe (using a new clean soft cloth or bounty paper towel) with a good quality streak free glass cleaner.

**American Car Craft LLC
18924 Sakera Rd Hudson, FL. 34667
Ph 727.861.1500 Fax 727.861.1520
www.americancarcraft.com**