



AMERICAN CAR CRAFT INSTRUCTIONS

C6 CORVETTE STAINLESS STEEL RETRO GRILLE

PART#042038patent pending



Your new retro grille comes to you preformed however it will be necessary to force the grille into and onto the factory grilles horizontal rib.

1. Carefully and accurately tape your grille opening completely top, bottom and sides using a 2" to 3" masking tape. This step is done in order to protect your paint during installation.
2. Your grille comes to you with four zip ties attached. Allow these ties to enter the grille opening so that they set above and below the center horizontal rail of the factory grille.
3. Carefully place the grille into position. Using both hands grip the grille and squeeze the center bar onto and into the factory grille horizontal bar. You will find that it will take the shape of the grille and pretty much stay in position.

4. Lay with your back to the floor reach thru the front grille with your fingers of one hand as you reach under the car and around the back of the grille with your other hand align the two ends of the zip tie attach them and pull to fasten securely. Apply this step to all four zip ties. Adjust the grilles position so that it sits evenly and securely in the factory opening.

5. Remove the protective masking tape.

If any questions occur during installation please contact American Car Craft at 727-861-1500.

Note: Care must be taken when cleaning your grille. It is a good idea to lightly dust your grille with a clean soft cloth first in order to prevent any particles from scratching it. Then wipe using a new clean soft cloth with a good quality streak free glass cleaner.

Thank you and enjoy your new purchase!

AMERICAN CAR CRAFT
18924 SAKERA RD HUDSON FL 34667
Phone: 727 861-1500 Fax: 727 861-1520
www.americancarcraft.com