



**AMERICAN CAR CRAFT INSTRUCTIONS**

**C6 Corvette Z06 Stainless Laser Mesh Lower Air Dam Grilles**

**PART # 042045**



**PARTS INCLUDED:**

**1-Adhesive Promoter Packet**

**2-Laser Mesh Grille Inserts w/attachment Tape**

**2-Black Air Deflector Plates**

1. Remove the two factory air dam screws just behind the air dam opening.
2. Set the new grille in position behind the hole and shape the grille by hand so that it matches the shape and contour of the factory air dam and also so that the two holes in the new grille match up with the two screw hole locations.
3. For ease of installation your new grille comes with an attachment tape. Thoroughly clean the area where the two factory screws were removed with rubbing alcohol. Peel the red release liner from the grille and set the grille in position. The tape has been added to allow the grille to remain in place leaving your hands free to re-install the two factory screws. Simply replace the two screws for each of the grilles to complete the installation.

IF ANY QUESTIONS OCCUR DURING INSTALLATION PLEASE CALL  
AMERICAN CAR CRAFT @ 727-861-1500.

Thank you and enjoy your new purchase!

**AMERICAN CAR CRAFT**  
**18924 SAKERA RD HUDSON FL 34667**  
**Phone: 727 861-1500      Fax: 727 861-1520**  
**[www.americancarcraft.com](http://www.americancarcraft.com)**