



**AMERICAN CAR CRAFT INSTRUCTIONS**

**C6 CORVETTE STAINLESS STEEL 4PC BRAKE PAD COVERS**

**PART#042046**



- 1. Jack up your car and place it on a pair of jack stands for safety then remove the wheel.**
- 2. Remove both caliper retaining bolts and remove caliper.**
- 3. Compress the caliper piston slightly to create the clearance for the new brake pad cover.**

4. Remove the outer brake pad and apply a small smear of household silicone to the back of your new stainless pad plate and place it over the brake pad.
  
5. Reposition the pad and reposition brake caliper and tighten **SECURELY!**
  
6. Follow steps 1- 5 for your 3 remaining wheels.

**PLEASE NOTE:** These custom pad covers in **NO** way alter your braking system. American Car Craft and its distributors will not be responsible for any improper installations; such as loose bolts or improper placement that may cause any danger or damage in any way, shape or form. Please follow instructions carefully and be sure to put your brakes back together safely and securely!

If you have any questions during installation, please call American Car Craft at 727.861.1500.

**Thank you and enjoy your purchase!**

**AMERICAN CAR CRAFT**  
**18924 SAKERA RD HUDSON FL 34667**  
**Phone: 727 861-1500      Fax: 727 861-1520**  
**[www.americancarcraft.com](http://www.americancarcraft.com)**