



Taillight Covers Vinyl Blackout Kit 4pc

2005-2013



## AMERICAN CAR CRAFT INSTRUCTIONS

### C6 Corvette Vinyl Blackout

Part# 042072 Patent Pending



#### **PARTS INCLUDED:**

- 4-Black-Out Vinyl
- 1-Hard Squeegee
- 1-Soft Squeegee (Half)

#### **!!VERY IMPORTANT!!**

#### **!!PLEASE READ ENTIRE INSTRUCTIONS BEFORE BEGINNING THIS INSTALLATION!!**

1. The first step will be to thoroughly scrub clean the entire front surface of the factory taillight lens with rubbing alcohol to remove any and all road grime and dirt.
2. The next step will be to position the vinyl overlay and get yourself acquainted with their intended position. You should also get a good idea about how they will mount. This vinyl will mount dry.
3. Now that you have a good idea on how these will fit simply peel the back release liner and then carefully position the vinyl at one end and work your way to the other end of the taillight. Make sure that the vinyl is nice and straight and even from side to side. Using the soft squeegee, press the vinyl to the taillight lens as you gradually lay it down making sure not to create any air bubble along the way. If you do create an air bubble gently pull the vinyl back up a little and re-press the vinyl down and continue until you have completely set the vinyl to the taillight.
4. You have been provided with a small white hard squeegee. Do not use this squeegee to set the face of the vinyl but only to set the outer edges to the lens finishing the installation. Simply perform the same procedure for all four taillights.

**Thank you and enjoy your purchase!**

**If any questions occur during installation, please contact  
AMERICAN CAR CRAFT  
18924 SAKERA ROAD-HUDSON FLORIDA 34667  
Phone # 727-861-1500 Fax # 727-861-1520  
[www.americancarcraft.com](http://www.americancarcraft.com)**