



**AMERICAN CAR CRAFT INSTRUCTIONS**

**C6 CORVETTE STAINLESS TRIBAL SKULL TAILLIGHT COVERS**

**PART# 042073** patent pending



**PARTS INCLUDED:**

**4-Stainless Taillight Covers**

**2-Tubes of Adhesive Promoter**

**VERY IMPORTANT!! PLEASE READ ENTIRE INSTRUCTIONS BEFORE BEGINNING THIS INSTALLATION!!**

YOUR NEW COVERS COME TO YOU WITH A PROTECTIVE LINER. DO NOT REMOVE THIS LINER UNTIL INSTALLATION IS COMPLETE!

**These newly designed C6 taillight grills have been designed to install directly to the C6 taillight allowing you access to the light bulb in the event of replacement.**

1 .Thoroughly scrub clean the perimeter of all four taillights. This is a critical step to insure a good long term bond. Once this is done swipe the perimeter with the adhesive promoter tube supplied with your kit.

2. **(DO NOT SCRATCH YOUR PAINT!! you may elect to put some masking tape on your painted surface area) set each taillight cover in place and check the overall shape.** Your new grills come to you preformed to match your taillights however it will be necessary to further shape each grill by hand in order to achieve the best contoured fitment. Once you have shaped the grills simply peel the red release liner from the back of the grill and then carefully set them in place pressing firmly along the outer perimeter to set the bond. Go over the perimeter several times with high pressure and allow 24hrs to complete the bond.

3. Remove the protective liner. NOTE: You have been supplied with five strips of ¼ chrome trim. This trim is optional. If you take a close look at the taillight lenses before installation you will notice an irregular perimeter gap of the factory lenses. This gap is almost undetectable with the factory lenses in place but after applying you new grills this irregularity will become more apparent. We have supplied this chrome trim to eliminate this gap. If you elect to use this trim, simply apply a thin bead of adhesive promoter supplied with the trim to the painted surface directly in front of the grills perimeter. Then peel the release liner from the trim and apply the trim directly to the paint nice and tight against the grill. Start at one side of the lens screw tab and work your way around to the other side and then cut the trim to fit against the tab for the remaining side. You have been supplied with a fifth strip in the event you may ever have to change a bulb. The extra trim is added for replacement.

IMPORTANT TECH NOTE: Be sure to allow the top of the new grills to set behind the lens attachment screw in order to allow removal of the lens.

AMERICAN CAR CRAFT  
18924 SAKERA RD HUDSON FL 34667  
Phone: 727 861-1500 Fax: 727 861-1520  
[www.americancarcraft.com](http://www.americancarcraft.com)