



**AMERICAN CAR CRAFT INSTRUCTIONS**

**C6 CORVETTE LASER MESH C6 TAG FRAME  
PART#042079**



**PARTS INCLUDED:**

- 1-STAINLESS TAG BACK
- 1-CHROME TAG FRAME
- 2-6mm HEX HEAD BOLTS
- 2-CHROME PUSH ON TOP HATS
- 2-FLAT BLACK VINYL GRAPHICS

Your new license plate frame comes to you with a set of flat black vinyl graphic back drops. These are supplied to be placed directly to the paint just in back of the frame grille areas to simulate a real vent opening. To utilize these, place the frame in position and mark the grille mesh or perforated locations through the grille directly onto the paint with a pencil. Remove the frame and then carefully peel the vinyl from the paper sheet and

then apply the graphic using your thumb to iron the black vinyl to the paint at both locations. Then simply install the frame. This is the most simple and straight forward way to install these graphic inserts however if you find this method be a little tricky for you then try this:

Apply these back drops wet. This will allow you to slide the inserts around to the best position and then squeegee out the fluid to set the graphic. To do this mix a 32oz spray bottle of water with a few drops of Johnson's Baby Shampoo. Spray the solution to the paint and make sure the mixture sheets the paint and does not bead up. Once you have achieved a good solution simply spray the car as well as the graphic and slip the insert into position then squeegee it to set in place.

If you have any questions during installation, please call American Car Craft at 727.861.1500.

**AMERICAN CAR CRAFT**  
**18924 SAKERA RD HUDSON FL 34667**  
**Phone: 727 861-1500      Fax: 727 861-1520**  
**[www.americancarcraft.com](http://www.americancarcraft.com)**