



## AMERICAN CAR CRAFT INSTRUCTIONS

**C6 CORVETTE POLISHED BRAKE BOOSTER COVER (fits 2009-2010)**

**PART# 043012**<sub>patent pending</sub>



**PARTS INCLUDED:**

- 1-Stainless Brake Booster Cover
- 2-Chrome Nut Covers 120 NC

Your new accessory comes to you with a clear protective liner. This liner will help to keep your new parts clean during installation. You will be instructed when to remove the liner during the detailed installation.

1. Remove the two 10mm nuts securing the water tank and lift it out of its position and rest it over the alternator temporarily.

2. Remove the vacuum line and the two nuts securing the master cylinder. Pull the master forward off the two bolt studs.
3. Slide the new booster cover over the master cylinder booster.
4. Reposition the master onto the bolt studs remove the protective liner and tighten down the master and cover.
5. You have been provided with two decorative chrome nut covers. Apply a small dab of 100% clear household silicone to the covers and install them over the two factory bolts to finish the installation.
6. Replace and secure the factory water tank.

**If any questions occur during installation, please contact American Car Craft at 727-861-1500.**

**Thank you and enjoy your new cover.**

**AMERICAN CAR CRAFT  
18924 SAKERA RD HUDSON FL 34667  
Phone: 727 861-1500      Fax: 727 861-1520  
[www.americancarcraft.com](http://www.americancarcraft.com)**