



AMERICAN CAR CRAFT INSTRUCTIONS

C6 CORVETTE COMPONENT FRONT NOSE CAP

PART#043020_{patent pending}



ITEMS NEEDED:

Household Isopropyl Alcohol
Small Socket Set
Right Angle Pick

ITEMS PROVIDED:

4-Speed Clips
4- Flat Head Screws
Adhesive Promoter

Your nose cap comes to you with a protective liner; do not remove liner until final step.

1. Remove the bumper screws and factory clip nuts attaching the nose piece to the steel bumper. A right angle pick works best for this. Replace with the four speed clips and flat head screws provided. Tighten to a snug and flush position. The flat head screw will countersink itself as long as it is not over tightened.
2. Prep the entire area first with household isopropyl alcohol then wipe with the adhesive promoter provided. Be sure not to miss the area just under the rubber seal.
3. Your new nose piece is designed to permanently attach to the nose area via

3M attachment tape. Remove the red liner from the tape and line up the nose cap just under the rubber seal molding. Be sure to catch the entire small ridge running just under this molding and press firmly to set. Remove protective liner.

Note: Care must be taken when cleaning your cover. It is a good idea to lightly dust your cover with a clean soft cloth first in order to prevent any particles from scratching it. Then wipe (using a new clean soft cloth) with a good quality streak free glass cleaner.

If any questions or problems occur during installation, please contact American Car Craft at 727-861-1500.

Thank You and Enjoy Your Purchase!

**AMERICAN CAR CRAFT
18924 SAKERA RD HUDSON FL 34667
Phone: 727 861-1500 Fax: 727 861-1520
www.americancarcraft.com**