



AMERICAN CAR CRAFT INSTRUCTIONS

C6 CORVETTE POLISHED COMPONENT ZO6THROTTLE BODY COVER

Part # 043050 patent pending



PARTS INCLUDED:

- 1-Stainless Throttle Body Cover
- 1-Chrome Cap Cover w/Velcro
- 1-Pack of Adhesive Promoter

Your new cover comes to you with a protective liner. Do not remove liner until step 3.

1. Before you begin it will be necessary to slightly adjust the rotation of the factory mass flow sensor. You will notice the factory wire connector protruding up and outward towards the driver's side of the vehicle. This connector must be rotated downward slightly. You can do this by loosening the large hose clamp just enough to allow you to turn the connector down about half way between where it is now and the power steering reservoir. It may be necessary to remove the small rubber notch you will see at the hose clamp. You can easily slice it off using a razor blade or snap knife. Retighten.

2. Remove the power steering cap. Your new cover is designed to slip over the large cylindrical casting a top the throttle body on the passenger side and rolled over top of the throttle body and set directly on top of the power steering reservoir so that the factory cap can be positioned to hold this cover in place. At this time take a look at the overall fit and make any adjustments by hand to the shape so that the cover will look nice and straight.

3. Remove protective liner and replace the power steering cap.

4. Thoroughly clean the top of the factory cap with household rubbing alcohol then swipe the factory cap once with the adhesive promoter provided. You have been provided with a chrome cap cover remove the Velcro attachment cookie and install it onto the factory cap and press firmly to set. Then simply place your new cap cover in position.

Note: Care must be taken when cleaning your cover. It is a good idea to lightly dust your cover with a clean soft cloth first in order to prevent any particles from scratching it. Then wipe (using a new clean soft cloth) with a good quality streak free glass cleaner. PLEASE SEE ENCLOSED CARE SHEET!

**If any questions occur during installation, please contact American Car Craft at
727-861-1500.**

Thank you and enjoy your new purchase!

**AMERICAN CAR CRAFT
18924 SAKERA RD HUDSON FL 34667
Phone: 727 861-1500 Fax: 727 861-1520
www.americancarcraft.com**