



AMERICAN CAR CRAFT INSTRUCTIONS

CORVETTE Z06 OIL DRY SUMP COVER - POLISHED

PART #043097



PARTS INCLUDED:

- 1-Stainless Oil Dry Sump Cover
- 1-Sheet Metal Pilot Screw
- 1-Thumb Screw
- 1-Support Bracket w/Velcro
- 1-Zip Tie

Liner Information: Your new accessories will come to you with a protective surface liner. Leave this liner in place until the installation is complete to prevent finger prints and or possible scratches during installation.

1. Your new cover will set in place directly over the hoods safety hook and hood stop. Place the unit into position to check its fit and also to take a look at the large wire harness. Your new cover has been notched for this harness **however** since it is a wire harness you will need to **manipulate** it so that it will run through the notch provided in such a way as to not allow the new cover to chafe the harness in any way. We have provided a zip tie to help secure the harness to the required position.
2. The second step will be to remove the wiper cowl gasket and examine the end of the cover to determine just where to locate the covers support bracket. This bracket has been designed to be secured by the factory wiper cowl clip located closest to the covers end. Once you have selected the best location for the bracket simply pull

the factory clip off the wiper cowl then hold the support bracket in place and force the clip back onto the cowl securing the support bracket.

3. With the bracket in place position the new cover so that you will be able to mark the thumb screw hole to the hoods safety hook platform with a marker. Remove the cover and then drill a 5/32 pilot hole at that location. You have been provided with a single pilot screw of the same thread type. Use this screw to create the thread into your newly piloted hole by using a screw gun to run the screw in and out of the hole a few times to create a nice thread path for the thumb screw. Do not try to thread the thumb screw in before this procedure because this will damage the thumb screw. You want to be able to freely insert the thumb screw without binding. If the thumb screw binds run the pilot screw through again until you can achieve a nice free moving installation of the thumb screw. Your new cover will have a Velcro strip adhered to the underside this will connect to the Velcro attached to the bracket installed earlier.
4. Now that you have got everything ready simply set the new cover into place and secure it with the thumb screw provided. Remove the protective liner.

If any questions or problems occur during installation, please contact American Car Craft at 727-861-1500.

Thank You and Enjoy Your Purchase!

AMERICAN CAR CRAFT

18924 SAKERA RD HUDSON FL 34667

Phone: 727 861-1500

Fax: 727 861-1520

www.americancarcraft.com