

## **AMERICAN CAR CRAFT INSTRUCTION**

## C5/C6 CARBON FIBER SLOTTED ENGINE FLUID CAP COVER SET $PART \ \# \ 043098$



## **INCLUDES:**

6-Chrome Cap Covers 6-Attachment Cookies 1-Pack Adhesive Promoter

These new and unique caps are designed to set over the factory cap as a cosmetic cover only. These chrome plated steel caps are simple to attach and offer a nice clean look.

- 1. The first step for installation will be to thoroughly scrub the tops of each of the factory caps, the oil/water/washer fluid/brake fluid/power steering and clutch fluid if so equipped. Scrub them with alcohol to remove any surface contaminants then swipe the tops with the adhesive promoter provided.
- 2. You have been provided with 2" furry Velcro attachment cookies for each cap. Peel the release liner from the back of each cookie and firmly set them to the top of each factory cap.

- 3. The factory wind shield washer fluid cap will need to be trimmed slightly in order for the new cover to sit nice and centered. To do this, simply snip the finger tab as well as the attachment strap off the cap with a scissor.
- 4. The set will contain a cap cover that is angled for the oil cap and a thinner cover for the power steering cap. The remaining covers in your kit are for all other factory caps. Simply set them in place.

If any questions or problems occur during installation, please contact American Car Craft at 727-861-1500.

Thank You and Enjoy Your Purchase!

AMERICAN CAR CRAFT 18924 SAKERA RD HUDSON FL 34667 Phone: 727 861-1500 Fax: 727 861-1520

www.americancarcraft.com