



AMERICAN CAR CRAFT INSTRUCTIONS

Corvette C7 Brushed Replacement Doorsills Part #051003



PARTS INCLUDED:

2-Doorsills

2-Packs of Adhesive Promoter

Liner info: Your new accessories will come to you with a protective surface liner. Leave this liner in place until the installation is complete to prevent finger prints and or possible scratches during installation. This liner is required to remain on the part until you are instructed to remove it.

Video Installation Instructions Are Available Online:

<https://goo.gl/w83vVT>



Scan the above image with your preferred QR Code Scanning App to watch on your mobile device.

If any questions or problems occur during installation, please contact:

AMERICAN CAR CRAFT

18924 SAKERA ROAD-HUDSON FLORIDA 34667

Phone # 727-861-1500

Fax # 727-861-1520

www.americancarcraft.com