2014-2016



AMERICAN CAR CRAFT INSTRUCTIONS

C7 Corvette Stingray Polished/Illuminated Doorsill Overlays Part# 051016



PARTS INCLUDED:

- 2-Doorsills
- 2-Packs of Adhesive Promoter

Liner info: Your new accessories will come to you with a protective surface liner. Leave this liner in place until the installation is complete to prevent finger prints and or possible scratches during installation. This liner is required to remain on the part until you are instructed to remove it.

Installation Instructions Are Available Online:

http://youtu.be/x9D6r4qm-qg

Thank you and enjoy your purchase!

If any questions occur during installation, please contact AMERICAN CAR CRAFT 18924 SAKERA ROAD-HUDSON FLORIDA 34667 Phone # 727-861-1500 Fax # 727-861-1520

www.americancarcraft.com