



Rear Tag Frame Stingray Powder Coat Black w/
Brushed Stainless Steel "Stingray" Lettering

Universal



052082

AMERICAN CAR CRAFT INSTRUCTIONS

C7 Corvette "Stingray" Black/Brushed Stainless Part #052082



PARTS INCLUDED:

- 1-Tag Frame
- 2-M6-1.00x20mm Metric Hex Head Cap Screws
- 2-124NC 10mm Chrome Screw Covers

1. Remove screws from stock license frame.
2. Install new Tag Frame and install new hardware.
3. Snap Chrome Screw Covers over screw head.

Thank you and enjoy your purchase!

If any questions occur during installation, please contact

AMERICAN CAR CRAFT

18924 SAKERA ROAD-HUDSON FLORIDA 34667

Phone # 727-861-1500 Fax # 727-861-1520

www.americancarcraft.com