



Rear Tag Frame Powder Coat Black w/ Brushed
Stainless Steel "Corvette" Lettering CF Colors



AMERICAN CAR CRAFT INSTRUCTIONS

Corvette Stingray "Corvette" Black/Polished/Carbon Fiber Part# 052083



PARTS INCLUDED:

- 1-Black/Stainless/Carbon Fiber Tag Frame
- 2-M6-1.00x20mm Metric Hex Head Cap Screws
- 2-124NC 10mm Chrome Screw Covers

1. Remove screws from stock license frame.
2. Install new Tag Frame and install new hardware.
3. Snap Chrome Screw Covers over screw head.

Thank you and enjoy your purchase!

If any questions occur during installation please contact us.

**AMERICAN CAR CRAFT
18924 SAKERA ROAD-HUDSON FLORIDA 34667
Phone # 727-861-1500 Fax # 727-861-1520
www.americancarcraft.com**