



"Z06" Side View Mirror Trim With Real Carbon Fiber
Inlay 2pc

2017



52118

AMERICAN CAR CRAFT INSTRUCTIONS

C7 Z06 Side View Mirror Trim Z06 Inlaid, Real Carbon Fiber

Part #052118 Patent Pending



PARTS INCLUDED:

2-Stainless Mirror Trim Rings

This all new stainless trim ring accessory is an American Car Craft original idea that will add that cool little something to your car mirrors that would otherwise just be a plain OEM mirror.

1. Thoroughly clean the mirrors glass and perimeter with alcohol to remove any dust /dirt and wax.
2. Next, attach the carbon fiber vinyl to the mirror. Put the thicker portion on first starting on the lower inside part of the mirror and slowly slide your finger across the vinyl as you move towards the lower outside edge of the mirror.
3. Before you permanently attach the trim ring, set it onto the mirror to get an idea of just how it will set in place and get a look at the overall shape. Although it should not be necessary you may need to adjust the perimeter shape so that it matches the mirrors edge perfectly. The stainless is very thin and will allow you to do any adjustment by hand very easily. **TECH TIP:** Should any adjustments be necessary it would be best to set the trim ring on a totally flat surface such as a Formica countertop or piece of glass. This will help to prevent the trim ring from warping out of shape and will keep the ring to remain totally flat.
4. After you have got a good idea how the ring will sit, slowly remove the release liner from the back of the trim ring and then carefully set the ring in place pressing firmly along the entire perimeter to set the ring. Pressing firmly along the edge is very important to achieve a nice long lasting bond.

Thank you and enjoy your purchase!

If any questions occur during installation, please contact

AMERICAN CAR CRAFT

18924 SAKERA ROAD-HUDSON FLORIDA 34667

Phone # 727-861-1500 Fax # 727-861-1520

www.americancarcraft.com