



AMERICAN CAR CRAFT INSTRUCTIONS

WATER TANK COVER POLISHED

PART#053040 patent pending



PARTS INCLUDED:

- 1-Stainless Water Tank
- 1-6mm by 1" Bolt
- 1-Velcro Cookie Set
- 1-Packet of promoter
- 1-Chrome Cap 10mm
- 1-3/4 Chrome Cap

Your new accessory comes to you with a clear protective liner. This liner will help to keep your new parts clean during installation. You will be instructed when to remove the liner during the detailed installation.

1. The first step will be to remove the factory bolt on the left hand side on the factory water tank. This is what's holding the water tank into place.
2. Now you will need to clean the right side of the factory water tank with rubbing alcohol to get rid of any road grim or grease. You will also want to clean the top of the factory water tank cap. You were provided with a packet of adhesive promoter that you will apply to the part of the water tank and the cap top that you just cleaned. This will be used to attach the Velcro cookie that is attached to the new stainless water tank and the decorative cap for the water tank cap.
3. Now that the factory water tank is clean and prepped you can proceed to install the new stainless steel water tank. You will need to remove the cap on the factory water tank so you can install the Acc water tank. Once the cap is removed you can place the ACC water tank on top of the factory water tank. You were provided with a replacement bolt to replace the factory bolt you took out earlier. Peel the blue protective liner up around the hole and re bolt the water tank back down. You were provided with a decorative chrome cap from the bolt that will just snap on top of the bolt.
4. You can now remove the protective liner from the stainless steel water tank and re install the factory cap onto the water tank. You were also provided with a decorative chrome cap for the factory water tank cap .This is simply a Velcro cap and will stick right to the top of the factory cap.

If any questions occur during installation please contact American Car Craft at 727 861-1500. Thank you and enjoy your purchase!

AMERICAN CAR CRAFT
18924 SAKERA RD HUDSON FL 34667
Phone: 727 861-1500 Fax: 727 861-1520
www.americancarcraft.com