



Throttle Body Actuator Cover

2014-2016



053048

AMERICAN CAR CRAFT INSTRUCTIONS

C7 Corvette Polished Throttle Body Cover

Part # 053048 Patent Pending



PARTS INCLUDED:

- 1-Stainless Throttle Body Cover w/Velcro
- 1-Pack of Adhesive Promoter

Your new cover comes to you with a protective liner. Do not remove liner until step 3.

1. Before you begin it will be necessary to slightly adjust the rotation of the factory mass flow sensor. You will notice the factory wire connector protruding up and outward towards the driver's side of the vehicle. This connector must be rotated downward slightly. You can do this by loosening the large hose clamp just enough to allow you to turn the connector down about half way between where it is now and the power steering reservoir. It may be necessary to remove the small rubber notch you will see at the hose clamp. You can easily slice it off using a razor blade or snap knife. Retighten.
2. Remove the power steering cap. Your new cover is designed to slip over the large cylindrical casting a top the throttle body on the passenger side and rolled over top of the throttle body and set directly on top of the power steering reservoir so that the factory cap can be positioned to hold this cover in place. At this time take a look at the overall fit and make any adjustments by hand to the shape so that the cover will look nice and straight.
3. Remove protective liner and replace the power steering cap.
4. Thoroughly clean the top of the factory cap with household rubbing alcohol then swipe the factory cap once with the adhesive promoter provided. You have been provided with a chrome cap cover remove the Velcro attachment cookie and install it onto the factory cap and press firmly to set. Then simply place your new cap cover in position.

Thank you and enjoy your purchase!

If any questions occur during installation please contact

AMERICAN CAR CRAFT

18924 SAKERA ROAD-HUDSON FLORIDA 34667

Phone # 727-861-1500

Fax # 727-861-1520

www.americancarcraft.com