



AMERICAN CAR CRAFT INSTRUCTIONS

C7 Corvette Brushed 3pc Fender Covers

Part# 053101 Patent Pending



(Polished/Perforated finish shown in picture)

PARTS INCLUDED:

- 6-Chrome bottom cover w/ putty
- 1-Small bottom cover
- 1-Chrome bottom
- 1-3/4" Self taping screw

Video Instructions Online: <https://www.youtube.com/watch?v=50-7pD8Zby4>

If any questions occur during installation, please contact American Car Craft at
727-861-1500

Thank you and enjoy your purchase!

AMERICAN CAR CRAFT
18924 SAKERA ROAD-HUDSON FLORIDA 34667
Phone # 727-861-1500 Fax # 727-861-1520
www.americancarcraft.com