



AMERICAN CAR CRAFT INSTRUCTIONS

CAMARO SS BRUSHED STAINLESS DOOR KICK PLATES

PART # 101016 Patent Pending



PARTS INCLUDED:

- 2-Brushed Door Guards
- 2-Tape Test Strips
- 1-Abrasive Pad
- 2-Adhesive Promoter Packs

**YOUR DOOR GUARDS COME TO YOU WITH A PROTECTIVE LINER
DO NOT REMOVE PROTECTIVE LINER UNTIL STEP 7. NOTE: FLAME
GRAPHIC DOOR GUARDS DO NOT HAVE A PROTECTIVE LINER.**

!!!!!!VERY IMPORTANT!!!!

**PLEASE READ ALL INSTRUCTIONS BEFORE
BEGINNING YOUR INSTALLATION! YOU
MUST FOLLOW THESE INSTRUCTIONS**

EXACTLY OR YOUR NEW PANELS MAY NOT ADHERE.

- 1. BEFORE YOU BEGIN YOU MUST FIRST PREP THE DOOR PANEL IN ORDER TO ALLOW ADHESION!!!!.** You can do this by scrubbing the entire area first with household isopropyl alcohol. **Then closely follow the procedures outlined in the following steps!!!!**
- 2. If your door panels have been treated with armor-all or silicone coatings, installation will NOT work unless these treatments have been REMOVED with special chemicals! Household Isopropyl alcohol alone WILL NOT remove it. NOTE: Some doors have been treated at the dealerships and the factory before you purchased the car. So to be extra safe we suggest that you please refer to the SPECIAL PREPARATION INSTRUCTIONS enclosed. We can not be responsible for panels' not sticking due to improper door preparation!**
- 3. NOTE: YOU HAVE BEEN PROVIDED WITH A SMALL ABRASIVE PAD AND 2 TEST STRIPS ONE FOR EACH DOOR.**
- 4. Apply a strip of masking tape along the door panel above the contour to protect it. Lightly scuff the door panel along the entire perimeter to be mounted and wipe off any and all shavings. This step will produce a raw surface. Once this is done swipe the entire perimeter with the **adhesive promoter (provided)**. Allow a few seconds to dry. Use one of the test strips provided to test tackiness of the door panel area to be mounted. If all the procedures from the SPECIAL PREPARATION INSTRUCTIONS have been preformed properly your test strip **will** stick. If it does not stick perform the entire preparation again until it does. **DON'T ATTEMPT TO INSTALL YOUR DOOR GUARDS UNTIL YOUR TEST STRIPS ADHERE PROPERLY.****

Installation errors are NOT manufacturing defects and parts CANNOT be returned due to improper installation.

Before you remove the red liner for permanent attachment place the door guard into position and check the fit. Your panel comes to you preformed **however it will be necessary to form by hand** to insure a nice **perfectly contoured fit**. **When you are holding the panel up to the door it should lay flat and conform to the shape of the door without forcing it.** (In other words it should look like it is installed and not be protruding from the door panel in any way). **Please refer to the picture at the end of these instructions.** Make note of its position. PLEASE NOTE: Metal will not bend out of place itself so if it is properly formed and installed the panels will remain in place.

5. Remove the red liner (**be sure not to touch the adhesive**) and carefully reposition the door guard, press firmly on the panel to set.
6. Remove protective liner. Then repeat steps 1-7 for the other door.

If any questions occur during installation please contact American Car Craft @ 727 861-1500.

Thank you and enjoy your purchase!

Note: Care must be taken when cleaning your door guards. It is a good idea to lightly dust your door guards with a clean soft cloth first in order to prevent any particles from scratching them. Then wipe (using a new clean soft cloth) with a good quality streak free glass cleaner.

This is how your installed panels are designed to fit on your door panel.

AMERICAN CAR CRAFT
18924 SAKERA RD HUDSON FL 34667
Phone: 727 861-1500 Fax: 727 861-1520
www.americancarcraft.com