



AMERICAN CAR CRAFT INSTRUCTIONS

CAMARO STAINLESS FLAME REAR EMBLEM TRIM

PART# 102018_{patent pending}



PARTS INCLUDED:

- 1-Stainless Rear Emblem Trim
- 1-Adhesive Promoter Tube

Your emblem trim is designed to go around your rear factory emblem and attach directly to the painted surface.

1. Clean the area around the rear emblem with household rubbing alcohol to remove any wax and dirt then swipe the area once with the adhesive promoter tube provided.
2. Place the trim into position to familiarize yourself with the placement before removing the liner. It **WILL BE** necessary to **HAND FORM** the bezel to **CONFORM** to the shape of the car doing this will prevent any possibility of the bezel popping loose or lifting long term.

3. Once it is fitted properly peel the release liner from the back of the bezel and carefully place it around the rear emblem. Press firmly to set.

DO NOT GET WET FOR 24 HOURS.

**IF ANY QUESTIONS OCCUR DURING INSTALLATION PLEASE
CALL AMERICAN CAR CRAFT AT 727.861.1500.**

THANK YOU AND ENJOY YOUR PURCHASE!

**AMERICAN CAR CRAFT
18924 SAKERA RD HUDSON FL 34667
Phone: 727 861-1500 Fax: 727 861-1520
www.americancarcraft.com**