



**AMERICAN CAR CRAFT INSTRUCTIONS**

**POLISHED CAMARO 6PC REAR QUARTER TRIM**

**PART #102020** patent pending



**PARTS INCLUDED:**

6-Stainless Inserts

2-Adhesive Promoter Tubes

Your vents come to you with a protective liner. Do not remove liner until installation is complete.

1. Each of the six stainless inserts can only fit to their unique spot on the quarter panel. The first step will be to prepare the surface for installation by thoroughly scrubbing the six areas first with rubbing alcohol to remove all wax and dirt. Once this is done swipe the six areas once with the adhesive promoter snap tubes provided.

2. Each of the inserts comes to you flat. **IMPORTANT:** In order to prevent any possibility of the inserts popping away from the paint you **MUST** gently form the contour of the body to the insert. Place each insert in place to confirm its shape.
3. It **WILL BE** necessary to **HAND FORM** the inserts to **CONFORM** to the shape of the car doing this will prevent any possibility of the inserts popping loose or lifting long term.
4. Before you permanently stick the inserts to the paint practice placing them into position a couple of times. The attachment adhesive is very aggressive and will not allow you to reposition them once they have made contact. It is important to go slowly placing each insert perfectly into position. Once this is done press along the entire length of each insert to permanently set them to the paint.

**If any questions occur during installation, please contact American Car Craft at 727-861-1500.**

**AMERICAN CAR CRAFT**  
**18924 SAKERA RD HUDSON FL 34667**  
**Phone: 727 861-1500      Fax: 727 861-1520**  
**[www.americancarcraft.com](http://www.americancarcraft.com)**