



AMERICAN CAR CRAFT INSTRUCTIONS

CAMARO POLISHED SIDE MARKER LIGHT BEZELS

PART#102023 paten pending



PARTS INCLUDED:

- 4-Stainless Side Marker Bezels
- 1-Adhesive Promoter Tube

Your side marker bezels are designed to attach directly on the side marker lens.

1. Clean each side marker lens with household rubbing alcohol to remove any wax and dirt then swipe the area once with the adhesive promoter provided.
2. Place each bezel into position to familiarize yourself with each placement before removing liner. **VERY IMPORTANT:** It will be necessary to hand form the bezels to conform to the shape of the car before installing; doing this will prevent any possibility of the bezel popping loose or lifting long term.
3. Once they are fitted properly peel the release liner from the back of each bezel and carefully set them nice and evenly around each light. Press firmly to set.

DO NOT GET WET FOR 24 HOURS

IF ANY QUESTIONS OCCUR DURING INSTALLATION PLEASE CONTACT AMERICAN CAR CRAFT AT 727-861-1500

AMERICAN CAR CRAFT
18924 SAKERA ROAD-HUDSON FLORIDA 34667
Phone # 727-861-1500 Fax # 727-861-1520
www.americancarcraft.com