



AMERICAN CAR CRAFT INSTRUCTIONS

CAMARO 4PC WHEEL WELL MOLDING KIT

PART#102028 patent pending



PARTS INCLUDED:

- 4-Chrome Molding Lengths
- 2-Adhesive Promoter Packs

This new kit comes to you pre cut to the length and angle of each wheel well opening.

1. Thoroughly scrub clean all four wheel wells with rubbing alcohol to remove all wax and dirt.

2. Swipe the adhesive promoter along the wheel well at all four locations and allow a few seconds to dry.

3. Each of the moldings has been marked for placement. F.D. Front Driver etc.. Peel a small length of the red release liner from the back of the molding and then set the exposed adhesive at the side of the wheel well. Place the correct end of the molding directly to the paint and work the molding along the fender edge as you pull the liner until you reach the other side then press firmly to set the molding. Because it can not be exactly calculated how much you may or may not stretch the molding and temperatures can vary during installation you may have some extra molding by the time you have reach the end of the installation. Should this occur simply snip any excess molding off making sure that you achieve the same angle as the body.

DO NOT GET WET FOR 24 HOURS!

If you have any questions during installation please call American Car Craft at 727-861-1500.

Thank you and enjoy your purchase!

Care and Maintenance:

Wash and wax molding kits regularly to insure a beautiful long lasting finish.

**AMERICAN CAR CRAFT
18924 SAKERA ROAD-HUDSON FLORIDA 34667
Phone # 727-861-1500 Fax # 727-861-1520
www.americancarcraft.com**