



**AMERICAN CAR CRAFT INSTRUCTIONS**

## **CAMARO "SUPERCHARGED" GAS CAP TRIM - POLISHED**

**PART#102090** patent pending

(Brushed Shown)



### **PARTS INCLUDED:**

- 1-Stainless Gas Cap Trim w/tape
- 1-Adhesive Promoter Tube

Your new bezel is designed to fit on your factory gas cap.

1. Clean the painted area of your factory gas cap with household rubbing alcohol to remove any dirt and wax. Then swipe the area to be mounted once with the adhesive promoter tube provided.

2. **IMPORTANT:** Before permanent installation carefully place the new stainless bezel into position to check the shape of the cover. Make sure the overall shape of the new cover matches the shape of the curve of the car. It will be necessary to gently form the bezel by hand until you have achieved a nice perfect conformed fit to your cars curve without forcing. At this time you will need to make note of just how the cover sits in place making sure it sits nice and centered around your gas cap.
  
3. Peel the red release liner from the back of the stainless trim and carefully set it evenly around your factory gas cap and press firmly to set.

**DO NOT GET WET FOR 24 HOURS.**

**IF ANY QUESTIONS OCCUR DURING INSTALLATION PLEASE CONTACT  
AMERICAN CAR CRAFT AT 727-861-1500.**

**Thank You and Enjoy Your New Purchase.**

**AMERICAN CAR CRAFT  
18924 SAKERA ROAD-HUDSON FLORIDA 34667  
Phone # 727-861-1500 Fax # 727-861-1520  
[www.americancarcraft.com](http://www.americancarcraft.com)**